


OPTIFLEX KNEE C.P.M. MACHINE DETAIL SHEET



NJ / PA Knee & Shoulder Centers' OptiFlex® CPM Therapy How to Use The Machine Controller

FOR QUESTIONS OR PROBLEMS CALL:

856-273-8900

Ask for the Physician-Assistant (PA-C) on call or whoever is covering for C.P.M. problems



EXTENSION: To change the current angle of maximum knee straightening, press and hold the Extension button while simultaneously pressing either the UP or DOWN arrow button. (Note: UP = Less straightening; DOWN= More)



FLEXION: To change the current angle of maximum knee bending, press and hold the Flexion button while simultaneously pressing either the UP or DOWN arrow button. (Note: UP=More bending; DOWN= Less)



SPEED: To change the current Speed, press and hold the Speed button while simultaneously pressing either the UP or DOWN arrow button.



UP ARROW: While pressing and holding either the Extension, Flexion or Speed button, use the UP arrow button to increase the value of the specified function or limit.




DOWN ARROW: While pressing and holding either the Extension, Flexion or Speed button, use the DOWN arrow button to decrease the value of the specified function or limit.



EMERGENCY STOP/START: Press the STOP/START button to Halt or Start up machine movement.

DO NOT TOUCH THESE BUTTONS



MACHINE CONTROLLER